
## **M**SANSUI

## SERVICE MANUAL

# A-X750

MINI COMPONENT SYSTEM <Amplifier>



**Organization of System Component** 

System Name	Amplifier	Tuner	CD Player	Cassette Deck	Optional Speaker
MC-X750/X750L	A-X750	T-X950/X950L	CD-X950	D-X950	S-X750

#### CAUTION

- 1. Parts identified by the A symbol on the schematic diagram and the parts list are critical for safety.
- Parts identified by the ZL symbol of the schematic diagram and the paths and control of the zero.
   Use only replacement parts that have critical characteristics recommended by the manufacturer.
   Make leakage-current or resistance measurements to determine that exposed parts are acceptably insulated from the supply circuit before returning the appliance to the customer.

#### NOTICE

- Some printed circuit boards are not supplied assembled.
  - To separate these in this service manual, the stock numbers are not indicated for these boards. However, stock numbers for individual parts are indicated.
- The symbols EU, EG, IPT, SS and XX <EXPORT> on the parts list and the schematic diagram mean followings respectively.
  - EU ...... Manufactured for European market.
  - EG ...... Manufactured for F.R. Germany market.
  - IPT ...... Manufactured for Italy market.
    SS ...... Manufactured for Saudi Arabian market.
  - XX ......Standard Version.
  - XX ..... Standard Version.
  - <EXPORT>
  - NON MARK ...... Common Parts.
- Since some capacitors and resistors are omitted from parts lists in this service manual, refer to the Common Parts List for capacitors and resistors, which was issued on June 1987.
- Abbreviations in this Parts List are as follows.

#### - Abbreviations List -

C.R. S.R. Ce.R. M.R. F.R. N.I.R.	: Carbon Resistor : Solid Resistor : Cement Resistor : Metal Film Resistor : Fusing Resistor : Non-Inflammable	E.B.L. Ta.C. F.C. M.P.	: Low Leak Bi-Polar Electrolytic Capacitor : Taritalum Capacitor : Film Capacitor : Metalized Paper Capacitor
	Resistor	P.C.	: Polystyrene Capacitor
A.R.	: Array Resistor	M.M.C.	: Metalized Mylar
C.C.	: Ceramic Capacitor		Capacitor
C.T.	: Ceramic Capacitor,	A.C.	· Array Capacitor
	Temperature	V.R.	: Variable Resistor
	Compensation	S.V.R.	: Serni Variable
E.C.	: Electrolytic Capacitor		AResistor
E.L.C.	: Low Leak Electrolytic	SW.	: Switch
	Capacitor	Chip R.	: Chip Resistor
E.B.	: Bi-Polar Electrolytic Capacitor	Chip C.	: Chip Capacitor

### **Specifications**

### Power output (Front channel)

Min. RMS, both channels driven, from 20 to 20,000 Hz, with no more than 0.7% total harmonic distortion. 40 watts per channel into 6 ohms.

### Load impedance......6~16 ohms

#### Frequency response (at 1 watt)

### Signal to noise ratio (short-circuit, A-network)


BS, LD, VCR .....90 dB


### TONE CONTROL


I OHE CONTINUE	
BASS	± 8 dB (63Hz)
MID	±8dB(1 kHz)
	± 8 dB (6.3 kHz)

\* Design and specifications subject to changes without notice for improvements.









Parts List(Front View)				
Parts No	Stock No	Description		
1	05111100	Front Panel, (GOLD)		
1	05111200	Front Panel, (BLACK)		
2	05160100	Front Panel, Aluminume (GOLD)		
2	05157000	Front Panel, Aluminume (BLACK)		
3	05100700	Bonnet (GÖLD)		
3	05091000	Bonnet (BLACK)		
4	05111500	Knob, LOUDNESS/BALANCE (GOLD)		
4	05111600	Knob, LOUDNESS/BALANCE (BLACK)		
5	05128100	Master VR Knob Assy (GOLD)		
5	05128200	Master VR.Knob Assy(BLACK)		
6	05095600	Logo Badge		
7	05091500°	RS Filter		
8	05101600	DI Indicator		
9	05157200	2P Knob, DUET (GOLD)		
9	05153600	2P Knob, DUET (BLACK)		
10	05098300	Knob,MIC Level 1/2(GOLD)		
10	05097810	Knob, MIC Level 1/2(BLACK)		
11	05149900	Leg		
12	27902510	Leg Sheet		
13	49600500	MIC 1,2 Jack		
14	49600600	PHONES Jack		
15	05111700	Knob, BASS/TREBLE/MID(GOLD)		
15	05111800_	Knob, BASS/TREBLE/MID(BLACK)		

	Parts	List(Rear View	& Bottom View)
_	Parts	No. Stock No.	Description
_	1	49738410	15P FG Plug Cable(1)
	2	49738500	13P FG Plug Cable(2)
	3	49738600	7P FG Plug Cable(3)
	4	49374300	Strain Relief
Δ	. 5	48837700	Power Supply Cord < SS,XX>
Δ	. 5	49299300	Power Supply Cord < EU, IPT, EG>
	6	46549200	4P Speaker Terminal
	7	49622900	2P Surround Output Terminal
Δ	. 8	15041609	Power Transformer < SS,XX>
Δ	8	15041605	Power Transformer < EU, IPT, EG>
Δ	9	48175200	Voltage Serector Plug < SS,XX>



# 3. INTERIOR BLOCK DIAGRAM & TERMINAL FUNCTION OF IC


### •M38173M6-FP <System Control>

#### **Terminal Function**


PIN No.	1/0	Function	Active
1	1	A/D SW-1	
2	-	A/D SW-2	
3	1	A/D SW-3	
4	ı	A/D SW-4	
6	0	Serial Clock Output	
7	0	Serial Data Output	
10	0	Serial Clock Output for on Screen	
11	0	Serial Data Output for on Screen	
13	- 1	NTSC/PAL	
14	ı	Parity Input for on Screen	
15	ı	Short Detector	L
16	ı	Tuner Mute	
17	0	Voice Cancel Output 1	Can Dinate
18	0	Voice Cancel Output 2	See Block - Diagram on Page 1
19	0	Voice Cancel Output 3	
20	0	Voice Cancel Output 4	on Page 1
21	ŀ	JOG Direction Detector Input	
23	- 1	JOG Intercept Input	
24	l	Received Signal from Remote Controller	
25	ı	Hold Input	L
26	1	Sansui Serial Bus Input	
27		RESET	
30		OSC Terminal 4.19 MHz	
31		OSC Terminal 4.19 MHz	
32		0 V (GND)	
33	0	RESET Output	L
34	0	FL Micro Computor Chip Select	L
35	0	M6604 Chip Select	L
36	0	M50554 CS	L
		I	·

PIN No.	1/0	Function	Active
37	0	YSS215 Working Clock	L
38	0	LV3100 Chip Enable	
39	0	LC7536#0 Chip Enable	
40	0	LC7536#1 Chip Enable	
41	0	TC9162 Serial Clock	
42	0	TC9162 Serial Data	
43	0	TC9162#0 Strobe	
44	0		
45	0	FAN A	
46	0	FAN B	
47	0		
49	0	Power Out	L
50	0	Signal Mute	L_
51	0	Sansui Serial Bus	
53	0	Flat Output	Н
54	0	Center Mute	L
55	0	Rear Mute	L
61	0	LB1641 Motor Driver (UP Mode)	Н
62	0	LB1641 Motor Driver (DOWN Mode)	Н
69	0	Mute LED	Н
70	0	Stand by LED	Н
71	0	Efect REC LED	Н
73		5 V	
74		0 V	
75		0 V (GND)	
76		5 V	
78	ı	Defector of Volume Position	<u> </u>
79	ı	Check Input of Back up Voltage	
80	1	Thermal Detection	


### •GP1U561 <Remote Controller Receiver>




### •STK4164-2 <Power Amp.>



### •LB1641 <Driving Motor>



### •LC4966 <Analog Switch>



### 4. PARTS LIST OF CIRCUIT BOARD

4-1. F-6805 MAIN BOARD (STOCK NO.01324904=XX,SS,EU,IPT/01325008=EG)

	(STOCK NO.01324904=XX,SS,EU,IPT/01325008=EG				
	PARTS NO.	STOCK NO.	DESCRIPTION		
	TRANSISTOR				
	KQ1	46719900	DTC124ES		
	KQ2	46719800	DTA124ES		
	KQ3	46604301	25C3327		
	KQ4	46367201	2SA1048		
	KQ5	46367201	2SA1048		
	KQ6	46719900	DTC124ES		
	KQ7	46719900	OTC124ES		
	KQ8	46719800	OTA124ES		
	KQ9	46719900	DTC124ES		
*	IC				
	KIC1	4805680P	LC4966		
	KIC2	49263900	NJH20680		
	KIC3	03007700	NJM45580		
Δ	KIC4	49722700	STK4164-2		
+	30010				
	KD1	46464100	122133		
	KD3	46464100	122133		
Δ	KR16	49752500	100 OHM 1/SV N.1.K.		
Δ	KR18	49752500	100 OHM 1/5V N: L.R.		
	KR101	49757100	100 OHM 1/2V N.1.R. <eg></eg>		
	KC4	48663200	330PF 50V C.C.		
	KC5	48660200	47PF 50V C.C.		
	KC9	48663200	330PF 50V C.C.		
	KC10	48660200	47PF 50V C.C.		
	KC102	48662600	100PF 50V C.C'. <eg></eg>		
*	TRANSISTOR				
	LQ1	46367201	2SA1048		
	t02	46719900	DTC124ES		
*	DIODE				
	LD1	46464100	155133		
	LD2	46464100	122133		
	LD3	46464100	155133		
Δ	LRLI	49587400	RELAY 2H DG2402-0S		
		49730300	RELAY		
	TRANSISTOR				
Δ	HQ1	46614001	25A1283		
-	i IC				
Δ	HIC1	49440800	NJH78H12FA		
Δ	HIC2	49435600	NJH79H12FA		
Δ	HIC3	49440800	NJH78H12FA		
4	HIC4	49440500	NJM78MOGFA		
:	30010	40004100	DOCCOC		
	HD1	49634100	DBFGQE		
	HD3	46273600	DBB10B		
	ZENER DIODE	10510100	MT7 1970		
Δ	MDZ1	49516400	MTZJ278		
Δ	HDZ2	49676600	HTZJ5.6C		
٨	unt	10033500	22 ORM 2V N.I.R.		
Δ	HRI	46623500			
4	HR5	49751300	10 OHM 1/5V N.1.R.		

<	F-	68	05	>
---	----	----	----	---

PARTS NO.	STOCK NO.	DESCRIPTION
MR6,7	46248600	27 OHM IV N.I.R.
HC1	08680400	0.01 UF 500V C.C.
HC3	08680400	0.01 UF 500V C.C.
HC4	49114600	6800UF 50V EL.C.
HC5	49114600	6800UF 50V EL.C.
HC9	49723400	2200UF 25V EL.C.
MC10	49632400	1000UF 25V EL.C.
0Z1	46549200	SPEAKER TERMINAL 4P
# TRANGISTUR		•
VQ2	46367301	2SC2458
VQ3	46367301	2SC2458
‡ IC		
VICI	49723900	M38173M6-131FP
VX01	49777100	QUARTZ ELEMENT KBR-4.19MKS
\$ D100E		
V03	46464100	155133
VD4	46464100	155133
VD5	46464100	1SS133
VD6	46464100	1SS133
<b>V</b> 07	46464100	1SS133
80V	46464100	155133
VC1	48666200	0.01UF 16V C.C.
VC2	48666200	0.01UF 16V C.C.
NC3	48785900	3.3UF 5.5V EL.C.
VC10	48662600	100PF 50V C.C.

### 4-2. F-6806 AC FUSE BOARD

$\Box$	PARTS NO.	STOCK NO.	DESCRIPTION
7	KR51	49772400	5.6 OHM 10W CE.R.
۱ ک	KR52	49772400	5.6 OHM TOV CE.R.
-	KR131	49757100	10 OHM 1/2V N.I.R. <eg></eg>
1	KC132	48662600	100PF 50V C.C. <eg></eg>
ı	072	49622900	TERMINAL BOARD 2P
- 1	PF1	49593600	FLISE 2A <ss,xx></ss,xx>
. 1	PF1	49297200	FUSE 2A <eu, eg="" ipt,=""></eu,>
. 1	PF2	49593600	FUSE 2A <ss,xx></ss,xx>

#### 4-3. F-6820 MIC AMP. BOARD (STOCK NO.01325304)

PARTS NO.		STOCK NO.	DESCRIPTION
# TRANSISTOR	₹		
CQI		46367101	2SC2603
	OR	48058801	2SC1740S
CQ6		46719800	DTA124ES
	OR	49390400	RN2203
‡ IC			
GICI		49439500	NJM455RL
	OR	49541200	MS218AL
GIC2		49439500	NJM4558L
	OR	49541200	M5218AL
* D100E			
CD1		46464100	152133

_	r	£8	00	•

PARTS NO.	STOCK NO.	DESCRIPTION
GCI	48662800	ISOPF SOVC.C.
CC33	49417000	0.1UF 50V C.C.
GC34	49417000	0.1UF 50V C.C.
GVR1	49731300	20K_OHM V.R., MIC LEVEL
KR22	46248100	10 OHM 1W N.I.R.
<b>△</b> KR23	46624700	220.0HM 2V N.I.R.
110	49600500	MIC JACK I
0,12	49600500	MIC JÁCK 2
0.13	49600600	PHONE JACK

### 4-4. F-6821 KARAOKE FUNCTION BOARD(STOCK NO.01325404)

			R D (STOCK NO.01325404)
PARTS NO.		STOCK NO.	DESCRIPTION
* TRANSISTOR			0041115
GQ2		46367001	2SA1115
	OR	48058601	2SA933S
C03		48217800	DTC114ES
	OR	49388100	RN1202
CQ4		48217800	DTC114ES
	OR	49388100	RN1202
GQ5		48217800	DTC114ES
	OR	49388100	RN1202
FET .			
GFT1		46643500	2SK163-K1
	OR	46643501	2SK163-K2
	OR	46643502	25K163-L1
	OR	46643503	2SK163-L2
	OR	46643504	2SK163-M1
	OR	46643505	2SK163-H2
	OR	46643506	25K163-N1
	OR	46643507	25K163-N2
	OR	46643700	2SK246-Y
	OR	-46643701	2SK246-CR
	OR	46643702	2SK246-BL
CFT2		46643500	25K163-K1
	OR	46643501	25K163-K2
	ÓR	46643502	2SK163-L1
	OR	46643503	2SK163-L2
	OR	46643504	2SK163-MI
	OR	46643505	2SK163-M2
	OR	46643506	2SK163-N1
	OR	46643507	2SK163-N2
	OR		2SK246-Y
	OR	46643701	25K246-GR
	OR	46643702	25K246-BL
	UK	40043104	action (O. VO
i IC		40420EGA	n]m4558L
CIC3		49439500	M5218AL
	OR	49541200	n5218A1. NJM4558L
GIC4		49439500	•
	OR	49541200	MS218AL
GIC5		49439500	NJM4558L
	OR		MS218AL
GIC6		49439500	NJM4558L
cı.—	OR	49541200	M5218AL N M455RI
GIC7	On	49439500	NJM455BL M5218AL
CICO	OR		
CIC8	~-	49439500	NJM4558L M5218A1
	OR	49541200	M5218AL

### <F-6821>

PARTS NO.	STOCK NO.	DESCRIPTION
# DIODE		
GU2	46464100	155133
G03	46464100	155133
GD4	46464100	1SS133
G05	46464100	122133
* ZENER DIODE		
GDZ1	49676500	MTZJ5.68
GUZ2	49675800	HTZJ4.7A
C	R 49675900	MTZJ4.7B
C	R 49676000	HTZJ4.7C
GC27	48508400	10uF 16V Ta.c.
GC32	48103200	0.47UF 50V E.B.

#### 4-5. F-6823 TONE CONTROL BOARD (STOCK NO.01325604)

(310CK NO.01323004)			
PARTS NO.		STOCK NO.	DESCRIPTION
‡ IC			
110301		49439500	NJM4558L
	OR	49541200	M5218AL
JC324		48658600	10PF 50V C.C.
JVR303		49742800	100KB OHM V.R., TREBLE
JVR304		49742800	100KB OHM V.R.,MID
JVR305		49742800	100KB OHM V.R., BASS

### 4-6. F-6824 MASTER VOLUME BOARD (STOCK NO.01325704)


(STUCK NU-01325704)			
PARTS NO.		STUCK NO.	DESCRIPTION
‡ IC			
J1C300		49439500	NJM4558L
	OR	49541200	M5218AL
J1C302		48982600	LB1641
ZENER DIOD	E		
JDZ300		49675800	MTZJ4.7A
JVR300		49742700	150KB OHM V.R.,LOUDNESS
JVR301		49740500	100KB OHM V.R., MASTER
IVR302		49742900	250KW OHM V.R., BALANCE

#### 4-7. F-6825 KARAOKE SWITCHING BOARD (STOCK NO.01325804)

		807	11 D (310CK NO.01323001)
PARTS NU.		STOCK NO.	DESCRIPTION
‡ IC			
N1C300		49738900	GP1U561
TRANSISTOR			
мq300		48217800	DTC114ES
	UR	49388100	KN1202
NQ301		48217800	DTC114ES
	OR	49388100	RN1202
NQ302		48217800	DTC114ES
	OR	19388100	RN1202
LED			
NLD300		48841100	SEL3210, DUET ON
NLD301		48841200	SEL3910A,PRO
NLD302		48841200	SEL3910A,PRO
05300		49326300	TACT SV., DUET ON/OFF
05301		49326300	TACT SV., DUET MODE


### 5. PARTS LOCATION ON CIRCUIT BOARD

### 5-1. F-6805 Main Board




a⊋83-∃\_ **6806** 


### 5-3. F-6820 MIC Amp. Board




### 5-4. F-6821 KARAOKE Function Board




5-5. F-6807 Relay Board A
Component Side



#### 5-6. F-6824 Master VR. Board Component Side



5-7. F-6825 KARAOKE Changing Switch Board Component Side





### 5-9. F-6823 Tone Control Board


5-8. F-6808 Relay Board B


Component Side


6808 0 0 0 0 0 0





















### 7. PACKING LIST & ACCESSORY LIST



### Accessory List

Parts No	Stock No	Description
	49746400	Remote Controller,RS-G7 (MC-X750/L)
	49631200	ÀM Loop Antenna
	07563000	Antenna Holder < SS, EU, IPT >
	46051700	FM Anntenna
		Dry Battery,SUM-3
	19078900	Operating Instructions (MC-X750)
	19082100	Operating Instructions (MC-X750L)
	49335000	Antenna Matching Transformer (MC-X750L)

### Packing List

Parts No	Stock No	Description
1	05098410	Styrofoam Packing,pair (Tuner/ CD)
2	27867300	Vinyl Bag(Tuner)
3	27867400	Vinvl Bag(CD)
4	05095900	Styrofoam Packing,pair (Deck/AMP)
5	27594000	Vinyl Bag (Deck)
6	27343800	Vinyl Bag(AMP)
7	05153800	Carton Case (MC-X750 Black)
•	05158100	Carton Case (MC-X750 Gold)
	05159300	Carton Case (MC-X750L Black)
	05159400	Carton Case(MC-X750L Gold)



SANSUI ELECTRIC CO., LTD.:

SANSUI USA INC.:

SANSUI DEUTSCHLAND GMBH:

New River Building. 10-14, Shinkawa 1-chome, Chuo-ku Tokyo 104, Japan PHONE: (03)5566-1024 FAX: (03)5566-1027 (International Division) 1290 Wall Street West, Lyndhurst, New Jersey 07071 U.S.A. 17150 South Margay Ave. Carson, California 90746 U.S.A. Paul-Ehrlich-Strasse 8, 6074 Rödermark 2, F. R. Germany

山水電気株式会社

東京都中央区新川1-10-14(〒104)